Product sheet

View product online

Description

Kitchen Knives and Scissors Sharpener, 4 Stages With Handle
- Kitchen knife and scissors sharpener made up of 4 stages, each of which is designed in a specific material that ensures excellent results.
- Measurements: 22 x 5.4 x 7 (alt) cm.
- Colour: green/black.
- It has 4 stages to achieve optimal results with any utensil, be it knives or scissors.
- High resistance and durability.
- Uniquely designed sharpening system: perfect for back sharpening.
- Non-slip rubber base and ergonomically designed handle, comfortable and safe.
- Ideal for sharpening knives, scissors and other kitchen utensils, sewing scissors, etc.
- Item also known as sharpener, stone sharpener, scissors sharpener, knife sharpener, handle sharpener, kitchen sharpener, etc
- Each stage is designed with a specific material to treat all defects and have a Excellent end result:
>Slot 1 - Diamond Coating (Preparation): Repairs damaged edges and balances the blade before sharpening.
>Slot 2 - Carbide Stone: Sharpens the blade and restores its shape to a V-cut.
>Slot 3 - Ceramic Stone (Polishing): Removes impurities and polishes the blade to make it as sharp as a razor.
>Slot 4 - Scissor sharpness.

Specifications

High	7
Width	8
EAN	8435450440199
Manufacturer	ORYX
Long	25cm
Weight (kg)	0,19
Depth	25

This document is based on the product page published in our store and is provided for information only. It is not contractual. It may contain errors or omissions and does not replace the manufacturer datasheet.

If you have any questions, contact our support team

Item downloaded on 30 October 2026