

Product sheet

Replacement chainsaw chain 40cm 730 002 bosch

Brand: BOSCH

Reference: ALM 3422.4003



40 cm replacement chainsaw chain compatible with Bosch models. Made from high quality materials to ensure a precise and long-lasting cut. Ideal for gardening and maintenance work. Easy to install, it offers optimal performance in all types of wood. Designed to provide safety and efficiency in every use.

[View product online](#)

Description

The Bosch 730 002 40 cm chainsaw replacement chain is the perfect solution to keep your gardening tool in top condition. Made from high-quality materials, this chain guarantees a precise and long-lasting cut in all types of wood, from the softest to the hardest.

Its easy installation makes it ideal for any user, whether professional or amateur, looking for optimal performance in their maintenance and pruning work. This replacement chain is designed to provide safety and efficiency in every use, allowing you to carry out your tasks quickly and accurately.

With the Bosch 730 002 40 cm chainsaw replacement chain, you can enjoy a high-quality product that will help you keep your garden in perfect condition. Don't worry about the durability of your chainsaw, with this replacement you can continue working as efficiently as the first day.

Don't miss the opportunity to purchase this high-quality replacement chain and enjoy a precise and long-lasting cut in your gardening work. Get yours now!

Specifications

EAN	3165140771467
Manufacturer	BOSCH

may contain errors or omissions and does not replace the manufacturer datasheet.

[If you have any questions, contact our support team](#)

Item downloaded on 19 October 2026